

# AeroGraphics

*The Original Aircraft Lettering Company*



## Grumman AA5 - AA5B Exterior Kit PAGE 1 of 1

NOTE: Modifications and changes to accommodate your specific aircraft will be made at NO EXTRA CHARGE.  
Partial kits available upon request.

**IF YOU HAVE ANY QUESTIONS PLEASE CALL!**

Phone: 1-800-336-9633    [www.aerographics.com](http://www.aerographics.com)    Fax: 1-970-461-2065

<b>NO STEP</b> <b>NO STEP</b>	<b>NO PUSH</b> CLOSE CANOPY WITH LATCH HANDLE	AEROGRAPHICS 1405 N. PROSPECT DR. LOVELAND, CO 80538 800-336-9633	<b>NO PUSH</b> CLOSE CANOPY WITH LATCH HANDLE	<b>NO STEP</b> <b>NO STEP</b>
		GRUMMAN AA5-AA5B EXTERIOR KIT PAGE 1 OF 1		
<b>NO STEP</b> <b>NO STEP</b>	<b>NO PUSH</b> CLOSE CANOPY WITH LATCH HANDLE	← FUEL DRAINS	FUEL → DRAINS	<b>NO STEP</b> <b>NO STEP</b>
		<b>WARNING</b> AIR FILTER DETERIORATION CAN CAUSE ENGINE POWER LOSS. CONSULT AIRCRAFT MAINTENANCE MANUAL FOR AIR FILTER SER- VICING AND REPLACEMENT REQUIREMENTS.		
<b>HAND HOLD</b>			<b>HAND HOLD</b>	
FUEL MIN. 80/87 OCT. 26.3 U.S. GAL. TOTAL CAP. 19.0 U.S. GAL TO TAB			FUEL MIN 100 OCT. 26.3 U.S. GAL. TOTAL CAP. 19.0 U.S. GAL TO TAB	
FUEL MIN. 80/87 OCT. 26.3 U.S. GAL. TOTAL CAP. 19.0 U.S. GAL TO TAB			FUEL MIN 100 OCT. 26.3 U.S. GAL. TOTAL CAP. 19.0 U.S. GAL TO TAB	
EMERGENCY ACCESS CRASH LOCATOR BCN: PROTECT HANDS, PULL AND RIP COVER OPEN HERE MANUALLY ACTIVATE THE TRANSMITTER BCN BY PULLING THE TOGGLE SWITCH TOWARDS YOU TO THE ON POSITION			FUEL MIN. 80/87 OCT. 19 U.S. GAL. CAP.	FUEL MIN. 80/87 OCT. 19 U.S. GAL. CAP.
EMERGENCY ACCESS CRASH LOCATOR BCN: PROTECT HANDS, PULL AND RIP COVER OPEN HERE MANUALLY ACTIVATE THE TRANSMITTER BCN BY PUSHING THE TOGGLE TOWARD THE TOP OF THE FUSELAGE TO THE ON POSITION				

Phone: 1-800-336-9633    [www.aerographics.com](http://www.aerographics.com)    Fax: 1-970-461-2065