



Beechcraft BeechJet 400 Cabin Kit

PAGE 1 of 1

NOTE: Modifications and changes to accommodate your specific aircraft will be made at NO EXTRA CHARGE.
Partial kits available upon request.

IF YOU HAVE ANY QUESTIONS PLEASE CALL!

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

SEAT MUST BE LOCATED IN
FULL OUTBD POSITION
FOR TAKE OFF AND LANDING.
LIFE VEST UNDER SEAT CUSHION

COMPARTMENT CAPACITY
TOTAL COMPARTMENT CAPACITY
(INCLUDING BAGGAGE AND/OR PASSENGER)
NOT TO EXCEED 350 POUNDS
RIGHT HAND BAGGAGE LOADING
NOT TO EXCEED 100 POUNDS
SEE WEIGHT AND BALANCE SECTION OF
FLIGHT MANUAL FOR LOADING INSTRUCTIONS

COMPARTMENT CAPACITY
TOTAL COMPARTMENT CAPACITY
(INCLUDING BAGGAGE AND/OR PASSENGER)
NOT TO EXCEED 350 POUNDS
RIGHT HAND BAGGAGE LOADING
NOT TO EXCEED 100 POUNDS
SEE WEIGHT AND BALANCE SECTION OF
FLIGHT MANUAL FOR LOADING INSTRUCTIONS

**EXIT
RELEASE**

1. PULL COVER
2. PUSH LOCK
3. PULL HANDLE
4. PULL INWARD
5. LIFT AND ROTATE

INSTRUCTIONS

BEFORE TAKEOFF AND LANDING
1. RETURN SEAT BACK TO UPRIGHT POSITION.
2. STOW ARMREST
3. FULLY EXTEND HEADREST.
LIFE VEST UNDER BOTTOM CUSHION

**EXIT
RELEASE**

1. PUSH BUTTON ●
2. TURN HANDLE
UPWARD

INSTRUCTIONS

BEFORE TAKEOFF AND LANDING
1. RETURN SEAT BACK TO UPRIGHT POSITION.
2. STOW ARMREST
3. FULLY EXTEND HEADREST.
LIFE VEST UNDER BOTTOM CUSHION

COAT HANGER
MAX WEIGHT CAPACITY 25 LBS

COAT HANGER
MAX WEIGHT CAPACITY 25 LBS

**LIFE VEST STORED UNDER
FWD SEAT CUSHION**

**LIFE VEST STORED UNDER
FWD SEAT CUSHION**

**LIFE VEST STORED UNDER
FWD SEAT CUSHION**

**LIFE VEST STORED UNDER
FWD SEAT CUSHION**

12 VOLT DC OUTLET 12 VOLT DC OUTLET
FOR PC USE ONLY FOR PC USE ONLY

VENT VENT
KEEP CLEAR KEEP CLEAR

NO SMOKING

Phone: 1-800-336-9633 www.aerographics.com Fax: 1-970-461-2065